

Desired State Configuration with Azure Automation Service

Create a Virtual Machine on Azure Portal

Create a virtual machine







Create Automation Account

Give feedback


Create an Automation Account



Navigate to State Configuration under DSC (Configuration Management) . Add a configuration.



Upload PowerShell File from Local state.




```
The contents of File are:

Configuration NewConfig


{
    Node 'localhost'
    {
        # Install IIS features
        WindowsFeature WebServerRole {
            Name = "Web-Server"
            Ensure = "Present"
        }
    }
}
```

It will make ensure that web server role on windows server be always present. If not automatically with the help of Automation Account, it will install the web server role.


Under Nodes add VM



Navigate to Configuration and click on compile.




Select VM and connect to it.




Complete the registration. Change the configuration Mode to Applyand Auto Correct.




ОК





In VM, you can verify the DSC extension.



Take the RDP of windows VM









Web Server Role was installed.


Now Remove the web server role manually.

Under Manage click on Remove Roles and Feature. Disable web server role.



Click on Remove.





After sometime you will be able to see the web server role again. It was due to Automation DSC.

